

# HOBO® H22-001 Energy Logger

### Logs

- AC Current
- Temperature
- Relative Humidity
- DC Voltage
- 4 -20 mA
- AC Voltage
- Carbon Dioxide
- DC Current
- Kilowatt Hours
- Killowatts



- The HOBO Energy Logger is a modular, reconfigurable data logging system for Energy and Industrial monitoring applications. The 15-channel logger accepts up to three two-channel modules and six plug-and-play Smart Sensors (some sensors measure more than one parameter)
- Provides 12 volt excitation for third-party sensors
- Accepts pre-configured Smart sensors for fast set-up
- Signal conditioning modules retain configurations until changed, providing plug-andplay convenience for commonly used sensors
- Flexible power options include battery operation or AC power adaptor
- Powerful HOBOware software makes set-up and deployment fast and easy
- System capabilities can be expanded with Ethernet or remote data access communications

Available Measurements:	
AC Current	AC Voltage
Temperature	Carbon Dioxide
Relative Humidity	DC Current
DC Voltage	Kilowatt Hours
4 -20 mA	Kilowatts



D208/1 0610

Tempcon Instrumentation Ltd.
Unit 19, Ford Lane Business Park, Ford Lane
Ford, Nr. Arundel, West Sussex. BN18 0UZ
Tel: ++44 (0) 1243 558270 Fax: ++44 (0) 1243 558288

Email: info@tempcon.co.uk Web site: www.tempcon.co.uk



### **Specifications:**

- 512K non-volatile flash data storage
- Memory modes: Stop when full, Wrap around when full
- Operational indicators: 6 indicators provide logging and sensor network status
- 1 second to 18 hours, user specified interval (2 second minimum for two chan. S-FS-TRMSA)
- Sensor excitation: 12V DC at 200mA total
- Battery life: 1 year typical use (up to 75 mA excitation, 10 minute interval, 1 sec warm-up time)
- Immediate, Push-button, or Delayed-start logger start modes
- Battery type: 8 standard AA alkaline batteries included (for operation at -20°C to +50°C) Optional AA lithium batteries available for operation at -40°C to +140°C) AC Power: Optional 13.6V DC regulated AC adaptor (internal batteries to remain installed).
- Time Accuracy: 0 to 2 seconds for first data point and ±5 seconds per week at 25°C
- Logging Mode: immediate, timed delay, or trigger (button push) start operation, supports sampling operation for some sensors
- Data communication: Current readings while logging, read out while logging, readout when
- Operating Range: -20°C to +50°C with alkaline batteries, -40°C to +140°C with optional AA lithium batteries.
- Communication: RS-232 via 3.5 mm serial port or/and 9-pin D-Sub connector
- Sensor connectors: 6 off RJ-12 Smart Sensor jacks plus 3 FlexSmart module slots (which may have multiple parameters/channels)
- Dimensions: 156 x 84 x 46 mm Weight: 435 g

### **HOBO Energy Logger**



Battery operated, supplied without modules and sensors

Order Code: H22-001



AC Power Adaptor (100 to 240 VAC, 50 or 60 Hz supplied with European and UK adaptors)

Order Code: P-AC-1

FlexSmart TRMS Module Order Code: S-FS-TRMSA FlexSmart Analogue Module Order Code: S-FS-CVIA

#### Temperature/RH Sensors



Range: -40°C to +75°C (Temp Sensor)

Accuracy:  $\pm 0.2^{\circ}$ C (0 to  $\pm 50^{\circ}$ C)

Ranges: -40 to +75°C (Temp/RH Sensor)

10 to 90% RH

Accuracy:  $\pm 0.2^{\circ}$ C (0 to  $+50^{\circ}$ C) Order Code: S-TMB-M002 Order Code: S-TMB-M006 Order Code: S-TMB-M017 Order Code: S-THB-M002

Order Code: S-THB-M008

12-bit Temperature Sensor with 2m cable 12-bit Temperature Sensor with 6m cable 12-bit Temperature Sensor with 17m cable 12-bit Temperature/RH Sensor with 2m cable 12-bit Temperature/RH Sensor with 8m cable



Tempcon Instrumentation Ltd. Unit 19, Ford Lane Business Park, Ford Lane Ford, Nr. Arundel, West Sussex. BN18 0UZ Tel: ++44 (0) 1243 558270 Fax: ++44 (0) 1243 558288

Email: info@tempcon.co.uk Web site: www.tempcon.co.uk

D208/2 0610



### **Pulse Input Adaptor**



Connects pulse output sensors to Smart-sensor inputs. Compatible with electronic switch closures such as FET or open-collector outputs, or CMOS-level logic signals with a maximum input frequency of 120 Hz (120 pulses per

second). Order Code: S-UCC-M006

### WattNode kWh (requires Pulse Input Adaptor Order Code: S-UCC-M006)



The WattNode Delta-connection kWh Transducer works with Magnelab AC Current Transformers and a Pulse Input Adapter to provide True RMS kilowatt hours of energy used, even for loads with non-sinusoidal waveforms. Accuracy: 1.5% to 4% of reading (dependent

on CT used and line variation). Order Code: T-WNB-3D-240

Transducer WattNode 480 VAC 3-phase Delta/Wye kWh Order Code: T-WNB-3D-480

Transducer WattNode 208/240 VAC 3-Phase Wye kWh Transducer

WattNode 208/240 VAC 3-phase Delta kWh

Order Code: T-WNB-3Y-208

### Veris kWh (requires Pulse Input Adaptor Order Code: S-UCC-M006)



1 - phase, 300 Amp 3 - phase, 800 Amp The Veris AC kWhTransducer incorporates one split-core AC current sensor and two voltage leads and outputs a signal proportional to kilowatts of power (consumption). With an input voltage of 208 to 480 Volts AC rms, this transducer requires a Pulse Input Adapter. Accuracy: ±1%

Order Code: T-VER-8051-300 Order Code: T-VER-8051-800

### True RMS Current and Voltage (requires FlexSmart TRMS Module Order Code: S-FS-TRMSA)



The Magnelab AC Current 0-5 Amp AC Current Transformer (CT) is mounted around a current carrying wire to measure AC Amperage. This CT provides 333mV output proportional to current and is used with the FlexSmart TRMS Module for True RMS measurement of sinusoidal and non-sinusoidal waveforms. One or two CTs can be used with each FlexSmart TRMS Module.

Accuracy: ± 1% (from 10% to 130% rated voltage)

Magnelab Split-Core AC Current 0-5 Amp Order Code: T-MAG-SCT-005 Magnelab Split-Core AC Current 0-20 Amp Order Code: T-MAG-SCT-020 Magnelab Split-Core AC Current 0-50 Amp Order Code: T-MAG-SCT-050 Magnelab Split-Core AC Current 0-100 Amp Order Code: T-MAG-SCT-100 Magnelab Split-Core AC Current 0-200 Amp Order Code: T-MAG-SCT-200 Order Code: T-MAG-SCT-600 Magnelab Split-Core AC Current 0-600 Amp

### Magnelab AC Voltage (requires FlexSmart TRMS Module Order Code: S-FS-TRMSA)



The Magnelab 150-Volt AC Potential Transformer is used with the FlexSmart TRMS Module to provide accurate measurement of AC voltage. One or two PTs can be used with each FlexSmart TRMS module. Accuracy ±1% (from

10% to 130% of rated voltage). Order Code: T-MAG-SPT-150 Order Code: T-MAG-SPT-300 Order Code: T-MAG-SPT-600

0 - 50 Volt 0 - 300 Volt 0 - 600 Volt



Tempcon Instrumentation Ltd. Unit 19, Ford Lane Business Park, Ford Lane Ford, Nr. Arundel, West Sussex. BN18 0UZ Tel: ++44 (0) 1243 558270 Fax: ++44 (0) 1243 558288 Email: info@tempcon.co.uk Web site: www.tempcon.co.uk D208/3 0610



### Veris kW Kilowatt Transducer (requires FlexSmart Analog Module Order Code: S-FS-CVIA)

The Veris AC Kilowatt Transducer incorporates three split-core AC current sensors and three voltage leads and outputs a signal proportional to kilowatts of power (demand). With an input voltage of 480 Volts AC rms, this transducer requires a FlexSmart Analog Module. Accuracy ±1%

Order Code: T-VER-8044-100

480 V, 100 Amp Kilowatt Transducer

#### Ashcroft Gauge Pressure Sensor (requires FlexSmart Analog Module Order Code: S-FS-CVIA)



The Ashcroft Gauge Pressure Sensor provides precision pressure measurements in compressed air systems, water, or other compatible gases and fluids with an accuracy of ±1% FS from -20° to 85°C and only ±1.5% FS -40° to -20°C and 85° to 125°C

0 - 100 psigOrder Code: T-ASH-G2-100 0 - 200 psigOrder Code: T-ASH-G2-200 Order Code: T-ASH-G2-500 0 - 500 psig

### Setra Differential Air Pressure (requires FlexSmart Analog Module Order Code: S-FS-CVIA)



Setra Differential Air Pressure

± 1 % Accuracy

0 - 0.25" WC Order Code: T-SET-265-R25 0 - 1" WC Order Code: T-SET-265-001 0 - 2.5" WCOrder Code: T-SET-265-2R5 0 - 5" WCOrder Code: T-SET-265-005 0 - 10" WC Order Code: T-SET-265-010

## Ductmount RH/Temp Transmitter (requires FlexSmart Analog Module Order Code: S-FS-CVIA)



The Vaisala Duct-mount RH/Temp temperature and humidity transmitter offers reliable operation and mounts to air ducts. It provides an RH measurement range of 10 to 90% RH and temperature measurement range of -10° to 60°C. Accuracy: Better than ± 3% RH @ 25°C, ± 0.3°C temp @ 25°C

Ductmount RH/Temp Transmitter Order Code: T-VAI-HMD-40Y

### Carbon Dioxide/Temperature (requires FlexSmart Analog Module Order Code: S-FS-CVIA)



The Telaire 7001 Co<sub>2</sub> Monitor measures and displays CO<sub>2</sub> and temperature data simultaneously with a measurement range of 0 to 4000 ppm. Operates on 6 VDC from external AC/DC Adaptor or four AA batteries (not included). Measurement resolution ±1 ppm.

Order Code: TEL-7001 Order Code: UKPSU Order Code: CABLE-2070

Telaire 7001 Carbon Dioxide/Temp Monitor AC/DC Adaptor for UK use

CO2 and Temp output cable to FlexSmart Analog

Module

D208/4 0610



**Tempcon Instrumentation Ltd.** Unit 19, Ford Lane Business Park, Ford Lane Ford, Nr. Arundel, West Sussex. BN18 0UZ Tel: ++44 (0) 1243 558270 Fax: ++44 (0) 1243 558288

Email: info@tempcon.co.uk Web site: www.tempcon.co.uk



DC Current Transducer (requires FlexSmart Analog Module Order Code: S-FS-CVIA)

(A)

Range: 0-20/40/80 ADC slide-switch selectable Sensor Supply Voltage: 12-24 VAC/DC - (12 volts

supplied by logger module)

Accuracy: ±3% FS combined linearity, hysteresis

and repeatability

4-20mA or 0-5VDC output signal to FlexSmart

Analog Module:

Order Code: T-VER-H970-080

### **Order Codes**

HOBO Energy Logger
AC Power Adaptor (European & UK )
FlexSmart TRMS Module
FlexSmart Analogue Module
Order Code: P-AC-1
Order Code: S-FS-TRMSA
Order Code: S-FS-CVIA

#### **Accessories**

Mounting Feet Kit

DIN Mount Kit

Order Code: A – H22 – MOUNT – 1

Order Code: A – H22 – DINMOUNT – 1

AC Power Adaptor

Smart Sensor Extension Cable (length 5m)

Smart Sensor Extension Cable (length 10m)

Smart Sensor Extension Cable (length 25m)

1 – to – 2 Sensor Adaptor (when used with Smart

Order Code: P – AC – 1

Order Code: S – EXT – M005

Order Code: S – EXT – M010

Order Code: S – EXT – M025

Order Code: S – ADAPT – 5

Extension Cables allows a single Smart Sensor input

to branch to two Smart Sensors

#### Software

HOBOware PRO Software Order Code: BHW-PRO-CD

Serial Interface Cable

USB Serial Adaptor

Order Code: CABLE –PC–3.5

Order Code: CABLE–USB232

#### **Optional Communications**

HOBO U–Shuttle Order Code: U–DT–1

Serial to Ethernet Server Order Code: SERVER-DS203

D208/5 0610



Tempcon Instrumentation Ltd.
Unit 19, Ford Lane Business Park, Ford Lane
Ford, Nr. Arundel, West Sussex. BN18 0UZ

Tel: ++44 (0) 1243 558270 Fax: ++44 (0) 1243 558288

Email: info@tempcon.co.uk Web site: www.tempcon.co.uk