



**Fast USB
Download**



HOBO U12-001 Temperature Logger

- **Single Channel Data Logger**
- **Input: Temperature**
- **64K Memory**
- **43,000 12-bit Measurements**
- **USB Interface**

Measurement Range: -20°C to +70°C

Accuracy: ± 0.35°C (0 - 50°C)

12-bit resolution.

64K memory (43,000 12-bit measurements).

Complete download in 30 seconds via USB.

Programmable start time/date or pushbutton start.

Programmable sampling rate (1 Sec to 18 Hr).

Numerous event types (button push/release, host PC connection, low battery) stored to data file asynchronously during logging.

Battery level indication at launch.

Battery level recorded as a separate channel.

Blinking LED confirms operation.

Non-volatile memory retains data if battery fails.

1 Year user replaceable CR-2032 battery.

Operating Range: -20°C to +70°C, 5% to 95% RH

Easy launch and readout via HOBOWare software.

Real time logging.

Continue logging during data readout and logger status viewing.

Data can be viewed in three formats: graphical, tabular and deployment stastics.

Size: 58 x 74 x 22 mm Weight: 46 gms

Order Information

HOBO U12 Temp
HOBOWare PRO Software
for Windows/MAC
HOBOWare LITE Software
for Windows/MAC

Part No.

U12-001

BHW-PRO-CD

BHW-LITE-CD

HOBO U12-011 Temp/RH Logger

- **Two Channel Data Logger**
- **Input: Temperature + RH**
- **64K Memory**
- **43,000 12-bit Measurements**
- **USB Interface**

Measurement Range: -20°C to +70°C, 5% - 95% RH

Accuracy: ± 0.35°C (0 - 50°C), ± 2.5 % (10-90%)

12-bit resolution.

64K memory (43,000 12-bit measurements).

Complete download in 30 seconds via USB.

Programmable start time/date or pushbutton start.

Programmable sampling rate (1 Sec to 18 Hr).

Numerous event types (button push/release, host PC connection, low battery) stored to data file asynchronously during logging.

Battery level indication at launch.

Battery level recorded as a separate channel.

Blinking LED confirms operation.

Non-volatile memory retains data if battery fails.

1 Year user replaceable CR-2032 battery.

Operating Range: -20°C to +70°C, 5% to 95% RH

Easy launch and readout via HOBOWare software.

Real time logging.

Continue logging during data readout and logger status viewing.

Data can be viewed in three formats: graphical, tabular and deployment stastics.

Size: 58 x 74 x 22 mm Weight: 46 gms

Order Information

HOBO U12 Temp/RH
HOBOWare PRO Software
for Windows/MAC
HOBOWare LITE Software
for Windows/MAC

Part No.

U12-011

BHW-PRO-CD

BHW-LITE-CD

