



USB  
Connectivity



### **HOBO® U12-006 4ch Ext. Logger**

**A versatile 4 channel logger suitable for indoor use with inputs for 0-2.5v DC, and temperature, 4-20mA or AC current via external sensors (sold separately).**

- **64K Memory**
- **43,000 12-bit Measurements**
- **USB Interface**

Input: 0 to 2.5 Volts DC  
Accuracy:  $\pm 2\text{mV} \pm 2.5\%$  of absolute reading  
Measurement range: Dependant upon sensor  
12-bit resolution.  
Programmable start time/date or pushbutton start.  
Programmable sampling rate (1 Sec to 18 Hr).  
Numerous event types (button push/release, host PC connection, low battery) stored to data file asynchronously during logging.  
Battery level indication at launch.  
Battery level recorded as a separate channel.  
1 Year user replaceable CR-2032 battery.  
Blinking LED confirms operation.  
Non-volatile memory retains data if battery fails.  
Operating Range:  $-20^{\circ}\text{C}$  to  $+70^{\circ}\text{C}$   
Easy launch and readout via HOBOWare software.  
Complete download in 30 seconds via USB.  
Real time logging.  
Continue logging during data readout and logger status viewing.  
Data can be viewed in three formats: graphical, tabular and deployment stastics.  
Size: 58 x 74 x 22 mm Weight: 46g

#### **Order Information**

HOBO U12 4ch External  
HOBOWare PRO Software  
for Windows/MAC  
HOBOWare LITE Software  
for Windows/MAC

#### **Part No.**

U12-006

BHW-PRO-CD

BHW-LITE-CD

### **HOBO® U12-008 Outdoor Logger**

**A weatherproof and versatile 4 channel logger designed for outdoor and industrial use with inputs for 0-2.5v DC, and temperature, 4-20mA or AC current via external sensors (sold separately).**

- **64K Memory**
- **43,000 12-bit Measurements**
- **USB Interface**

Input: 0 to 2.5 Volts DC  
Accuracy:  $\pm 2\text{mV} \pm 2.5\%$  of absolute reading  
Measurement range: Dependant upon sensor  
12-bit resolution.  
Programmable start time/date or pushbutton start.  
Programmable sampling rate (1 Sec to 18 Hr).  
Numerous event types (host PC connection, low battery) stored to data file asynchronously during logging.  
Battery level indication at launch.  
Battery level recorded as a separate channel.  
Blinking LED confirms operation.  
Non-volatile memory retains data if battery fails.  
1 Year user replaceable CR-2032 battery.  
Operating Range:  $-20^{\circ}\text{C}$  to  $+70^{\circ}\text{C}$   
Easy launch and readout via HOBOWare software.  
Complete download in 30 seconds via USB.  
Real time logging.  
Continue logging during data readout and logger status viewing.  
Data can be viewed in three formats: graphical, tabular and deployment stastics.  
Size: 140 x 137 x 32 mm Weight: 200g

#### **Order Information**

HOBO U12 4ch Outdoor/Industrial  
HOBOWare PRO Software  
for Windows/MAC  
HOBOWare LITE Software  
for Windows/MAC

#### **Part No.**

U12-008

BHW-PRO-CD

BHW-LITE-CD



**Tempcon Instrumentation Ltd.**  
Unit 19, Ford Lane Business Park, Ford Lane  
Ford, Nr. Arundel, West Sussex. BN18 0UZ  
Tel: ++44 (0) 1243 558270 Fax: ++44 (0) 1243 558288  
Email: [info@tempcon.co.uk](mailto:info@tempcon.co.uk) Web site: [www.tempcon.co.uk](http://www.tempcon.co.uk)

D221  
0909