




DISCONTINUED: HOBO UX90-006M Occupancy/Light (512K - 12 Meter)

Product Images



Short Description

The HOBO Occupancy & Light data logger monitors room occupancy and indoor light changes to identify occupancy patterns and determine energy usage and potential savings.

Description

The HOBO Occupancy & Light data logger monitors room occupancy and indoor light changes to identify occupancy patterns and determine energy usage and potential savings. The HOBO UX90-006 Room Occupancy/Light Logger is available in a [standard 128 KB memory model \(UX90-006\)](#) capable of 84,650 measurements and an expanded 512KB memory version (UX90-006M) capable of over 346,795 measurements.

Features:

- Measures room occupancy up to 12 meters away
- Auto-calibration of ON and OFF thresholds ensures reliable readings
- LCD screen displays signal strength, enabling proper logger placement
- [Optional light pipe](#) eliminates effects of ambient sunlight or other lighting sources

NOTE: HOBO loggers require a USB cable and [HOBOWare software](#) (free download).

Additional Information

Country of Manufacture	United States
Promotion	This product has been superseded by the UX90-006
Brand	Onset HOBO
Onset Product Series	UX90
Typical applications	Building Monitoring, Energy, Environmental (Indoor), Thermal Comfort
Measurements	Light On/Off, Occupancy

Additional Options

Eliminate the effects of ambient sunlight when monitoring room light usage	HOBO Light Pipe
HOBOWare Pro Software Options	HOBOWare Pro on USB Drive (USB cable included)
	HOBOWare Pro on CD (USB Cable Included)
	HOBOWare Pro - Download Only (USB cable NOT included)
USB Cable (included with HOBOWare Pro on USB Drive & CD)	HOBO U-Series to PC USB Cable