

Getting Started With SpecConnect FieldScout Pro

The following notes are intended to help you get started using your Bluetooth-enabled FieldScout device and associated FieldScout Pro account on SpecConnect.

SpecConnect Website

****This must be done before logging into Pro on the app***

1. You should receive an email from SpecConnect confirming creation of your account. If you don't see it within a few hours, please check that it wasn't routed to another folder (spam, junk, clutter, etc.)
2. Go to www.specconnect.net and click on [New User or Forgot Password](#).
3. Enter the email address used to create your account, and click on the *Reset Password* button - SpecConnect will email you a temporary password (which is case sensitive!).
4. Return to the SpecConnect login page and use your email address and the temporary password to log into your account.
5. Once your dashboard comes up, click on your name in the upper right-hand corner and select *Change Password* to personalize (your password must have at least one non-alphanumeric character and at least one uppercase letter).
6. Click on your name again, and select *User Preferences* to input your preferred units of measurement so that your readings will be displayed in a familiar format.
7. Functionality may be limited if your Bluetooth device has not yet arrived, but take some time to explore and get familiar with the site layout.

FieldScout Mobile App

1. It's free and available now, directly from your mobile app store (Ctrl+Click on the link below).
 - a. [Apple \(iOS Device\) – Click here for the App Store link](#)
 - b. [Android – Click here for the Google Play link](#)
2. The app includes both Basic and Pro functionality – you'll be using Pro with SpecConnect.
3. Basic is available immediately upon download. Pro requires login credentials.
4. Login to the Pro function using the same credentials as your SpecConnect account.
5. Create a new Course and Session. ****Any Course/Sessions created in Basic should no longer be used.***
6. Readings from the FieldScout Mobile App (when logged into Pro and paired to Bluetooth) are automatically transmitted to the Cloud for access through your SpecConnect portal.
7. Data can be logged using either the traditional grid pattern, or free form mode which uses your phone to georeference and overlay the readings on a satellite map image.

Bluetooth Device for TDR 300

1. [Click here for instructions on pairing](#) your Bluetooth device with the FieldScout Mobile App.
****It is important to pair from within the app – the device may not show on your phones available list.***
2. Some operating systems require you to grant access to the app within your phone settings.
3. You're ready to start taking readings...

Pulling it All Together

1. Log into the FieldScout Mobile App (Pro) and navigate to a Session to ready the app for pairing.
2. Plug the Bluetooth device into your TDR, power both on, and the app will show it as available to pair.
3. Once the wireless Bluetooth connection is established, all of your readings are sent from the TDR to your mobile device **AND** forward to SpecConnect.
4. Log into SpecConnect from anywhere you have an internet connection (desktop, tablet, etc.) to find your data already uploaded and ready for evaluation.
5. Your readings data can be viewed visually overlaid on a satellite image, as well as exported to Excel for further analysis.
6. This same functionality works with **TruFirm Turf Firmness Meter** when enabled with Bluetooth Smart. If your TruFirm is not already equipped, Bluetooth Smart upgrade is available.
7. SpecConnect FieldScout Pro can support multiple TDR & TruFirm devices with reduced cost add on subscription(s), so all your data can be accessed in one place.